LUBRICATION

3.1 GENERAL

This section details the procedures for lubricating M28 and M35 Teleprinters. Equipment should be thoroughly lubricated, but excess lubricant which might allow oil to drip or grease to be thrown on other parts shall be avoided. The following instructions supplement the information contained in this section.

- Use a squeeze can oiler to apply oil to points where it will adhere or where pressure is nominal.
- On small parts, a minimum amount of oil should be applied so that the oil remains on the part and does not run off.
- Excessive oil should be removed with a dry, lint free cloth.
- Special care must be taken to prevent grease or oil from contacting the following areas:
  - All electrical components, including terminals.
  - All magnet core faces and any surfaces which might contact them.
  - All parts normally touched by an operator, including the ribbon and paper handling areas.
  - All large flat areas.